
## **Quick Guide**


## Day One: Extraction of DNA From Food Samples


- 1. Find your screwcap tubes and label one "non-GMO" and one "test".
- 2. Weigh out 0.5–2 g of certified non-GMO food and put it into the mortar.




 Add 5 ml of distilled water for every gram of food. To calculate the volumes of water you need, multiply the mass in grams of the food weighed out by 5 and add that many milliliters.












- 7. Repeat steps 2–5 to prepare the test food sample.
- 8. Pipet 50 µl of ground test food slurry to the screwcap tube labeled "test". Recap tube.
- Shake or flick the non-GMO food and test food InstaGene tubes and place tubes in 95°C water bath for 5 min.
- Place tubes in a centrifuge in a balanced conformation and centrifuge for 5 min at max speed.
- 11. Store tubes in a refrigerator until next lesson.












## Day 2: Set Up PCR Reactions


 Number PCR tubes 1–6 and initial them. The numbers should correspond to the following tube contents:

Tube number	Master Mix	DNA
1	20 µl Plant MM (green)	20 µl Non-GMO food control DNA
2	20 µl GMO MM (red)	20 μl Non-GMO food control DNA
3	20 µl Plant MM (green)	20 μl Test food DNA
4	20 µl GMO MM (red)	20 μl Test food DNA
5	20 µl Plant MM (green)	20 µl GMO positive control DNA
6	20 µl GMO MM (red)	20 μl GMO positive control DNA


2. Place each tube in a capless microtube adaptor and place in the foam float on ice.



3. Referring to the table and using a fresh tip for each addition, add 20 µl of the indicated master mix to each PCR tube, cap tubes.



 Referring to the table and using a fresh tip for each tube, add 20 μl of the indicated DNA to each PCR tube, being sure to avoid the InstaGene pellet at the bottom of the tubes. Mix by pipetting gently up and down; recap tubes.





5. When instructed, place PCR tubes in thermal cycler.



## Day 3: Electrophoresis of PCR products


- 1. Set up your gel electrophoresis apparatus as instructed.
- Obtain your PCR tube from the thermal cycler and place in the capless microtube adaptor. Pulse-spin the tube for ~3 seconds.






Lane	Sample	Load volume
1	Sample 1: Non-GMO food control	
	with plant primers	20 µl
2	Sample 2: Non-GMO food control	
	with GMO primers	20 µl
3	Sample 3: Test food with plant primers	20 µl
4	Sample 4: Test food with GMO primers	20 µl
5	Sample 5: GMO positive DNA	
	with plant primers	20 µl
6	Sample 6: GMO positive DNA	
	with GMO primers	20 µl
7	PCR molecular weight ruler	20 µl
8	Leave empty	


 The run time and voltage will depend on the type of gel you are running. Run an agarose gel for 30 min at 100 V and run a polyacrylamide gel at 200 V for 20 min.








Polyacrylamide Gel




Agarose Gel Electrophoresis



Polyacrylamide Gel Electrophoresis

6. Stain in Fast Blast DNA stain. Refer to specific instructions depending on gel type.





Bio-Rad Laboratories, Inc.

Life Science Group Web site www.bio-rad.com USA (800) 4BIORAD Australia 02 9914 2800 Austria (01)-877 89 01 Belgium 09-385 55 11 Brazil 55 21 2527 3454 Canada (905) 712-2771 China (86 21) 6426 0808 Czech Republic + 420 2 41 43 05 32 Denmark 44 52 10 00 Finland 09 804 22 00 France 01 47 95 69 65 Germany 089 318 84-0 Greece 30 210 777 4396 Hong Kong (852) 2789 3300 Hungary 36 1 455 8800 India (91-124)-2398112/3/4, 5018111, 6450092/93 Israel 03 951 4127 Italy 39 02 216091 Japan 03-5811-6270 Korea 82-2-3473-4460 Latin America 305-894-5950 Mexico 55-52-00-05-20 The Netherlands 0318-540666 New Zealand 64 9 415 2280 Norway 23 38 41 30 Poland + 48 22 331 99 99 Portugal 351-21-472-7700 Russia 7 095 721 1404 Singapore 65-64153188 South Africa 00 27 11 4428508 Spain 34 91 590 52 00 Sweden 08 555 12700 Switzerland 061 717 95 55 Taiwan (886 2) 2578 7189/2578 7241 United Kingdom 020 8328 2000

Bulletin 5290 Sig 1204